
MODIFICATION WORK ORDER

User Guidance

Copyright© 2020 ALASKAR Technologies Confidential Information: This document contains the confidential and proprietary information of ALASKAR Technologies. Disclosure is restricted.



1.MOD Work Order.



1. The Mod WO sub-module is created for registering the procedure of specific modifications, which were created not by manufacturer (ex. Boeing), but your own company. Click on the MOD WO button



WO Package Line WO						Open'	Close'		
33079	False	202001-L0003							
33078	False	202001-L0002							
33077	False	202001-L0001							
1456	False	201801-L0001							
1445	False	201512-L0002	test		31/12/2015	TST	CRJ700		
1439	False	201512-A0001		~	0.444,0400.4.0				
1428	False	201212-L0001	A320	0	04/12/2012		A320-100		
1426	False	201205-L0002	NEW	0	30/05/2012		B737-500		
1425	False	201205-L0001	201205-L0001	0	30/05/2012		B737-500		
1422	False	201110-A0002	201110-A0002	0	30/10/2011	LY-STG	B737-700		
1421 1418	False	201110-L0001 201109-L0005	TEST NG	0	12/09/2011	IVETO	B737-700	4	
1410	False	201109-L0003	TEST	0	1210012011	ES-ABH	B737-500		
1417	False False	201108-A0003	201108-A0003	0	06/09/2011 24/08/2011		LJ-60		
1410	False	201108-A0002	201108-A0002	Ő	24/08/2011		LJ-60		
1379	False	201010-L0003	TEST	ŏ	01/10/2010		S340		

2. Select a Work Package ('WO Package') or a Work Order ('Line WO'). Use these tabs to switch between them.

3. Use these filters to find different documents quickly.

4. Select necessary line and double click.



-Select Work Order: ID, Close Status, EA WO Num, Cust WO Num, Rev, Date, AC Reg:									
Found 32 Line Work Orders:									
	WO Packa	age Line	wo						
	33076	False	201912-LM0001	123453			D-ABIR	B737-500	E3RTYUIOP";L
	33075	False	201906-LM0001	RWQTQTQ			ADDDD	NG900	DGREWTEW
	33074	False	201807-LM0001	TEST			D-ABIR	B737-500	THIS IS A TES
	1449	False	201709-LM0001	TEST			D-TESTOO	B737-500	TEST WO AC
	1433	False	201302-LM0004	FTWQTWQT			D-ABIT	B737-500	TWTQGT
	1432	False	201302-LM0003	FYRE			D-ABIU	735	RYT
	1429	False	201301-LM0001	536523		5	D-ABIR	B737-500	326362
	1423	False	201111-LM0001	NA			D-ABIR	B737-500	NEW TEST W
	1420	False	201109-AM000	201109-AM0007	0	01/12/2011	ESLBD	B737-300	Perform NRC:
	1419	False	201109-LM0006	TEST			D-ABIR	B737-500	TEST
	1415	False	201109-LM0002	NA			LY-STG	B737-700	PELESOS G.
	1414	False	201109-LM0001	NA			LY-STG	B737-700	TEST WO 1
	1412	False	201108-LM0004	201108-LM0004			ESLBD	B737-300	FIRST AID KIT
	1408	False	201108-LM0001	201108-LM0001			LYSTG	B737-700	PERFORM TO
	1407	False	201106-AM0001	201106-AM0001			LYSTG	B737-700	INSP. REMAR 🚽
	•								
1	201110-	A0002	B737-700	29083		LY-STG		6	
							_	<u> </u>	
								Print	Cancel

5. After the WO/ WP selection, double click a necessary modification for which a procedure should be created.

6. To print out the procedure of a particular modification, highlight it in the list of modifications and click on the Print button.



Modification Wash-Order Editor	_ 8 ×
Qose Print -10	Permission: FULL CONTROL
Modification Work Order Editor: A/C Reg. No: A/C Serial No: Modification Work OrderTitle: LY-STG 29083 WINGS - FLIGHT SURFACE - LE SLATS - MAIN TRACK DOWN-STOP ASSEMBLY PN: INSPECTION SN: Work Package Description:	MOD WO Num.: M201109-L0005-0003 OEM Doc Ref. No.: AD 2008-06-29 Customer Doc. No.: *
Customer Work Package ID: TEST NG	r test r
Bupdate Prepared By: Prepared By:	Revision Date / Number. 08/04/2008 00
COMPLY WITH INSTRUCTIONS AD 2008-06-29	

7. When you double click a modification, the Modification Editor opens. Write down the whole procedure (you may just make reference to another instruction) and enter a person, who prepares it ('Prepared By' field).

8. To save entered data, click on the Update.

9.To remove the procedure, use Delete.

10. Push "Print" button to print out the MOD WO.