
## **TASK CARD MATERIALS**



## 1. Task Card Materials.



1. The Task Card Materials sub-module registers all materials that are necessary for a work order completion.



se WO	Print Help	Permission	FULL	CONTROL			
lect Work Ord ound 20 Work		EA WO Num, Cust WO	Num,	Rev, Date, AC F	Reg:		
3079         False           3078         False           3077         False           3077         False           456         False           445         False           439         False           428         False           420         False           422         False           422         False           422         False           422         False           422         False           422         False           423         False           424         False           425         False           421         False           418         False           417         False	<ul> <li>202001-L0003</li> <li>202001-L0003</li> <li>202001-L0001</li> <li>201801-L0001</li> <li>201512-L0002</li> <li>201512-A0001</li> <li>201212-L0001</li> </ul>	A320 NEW 201205-L0001 201110-A0002 TEST NG TEST	0 0 0 0 0 0	31/12/2015 04/12/2012 30/05/2012 30/10/2011 12/09/2011 06/09/2011 24/08/2011	YL-BBS ES-ABH ES-ABH LY-STG LY-STG ES-ABH	B737-500 B737-500 B737-700 B737-700	
410 False	201108-A0002 201010-L0003	201108-A0002	0	24/08/2011 24/08/2011 01/10/2010	ES-PVI	LJ-60	•

2. Select a Work Order.

You may also select a Work order by clicking on the WO toolbar button.

All open Work Orders will be displayed by default. To view closed ones, tick the 'Close' field.

6	
Tasks Cards Materials Specification     Specification     Gose W0 Print Help     Permission: FULL CONTROL ID: 1426; WO Close: False; WO: 201205-L000;	2; Cust.WO: NEW; A/C Reg: ES-ABH
Image: Start	Materials List For Selected Task Card:     O6-101-01       Base Task Card:     06-101-01       Task Card:     06-101-01       Found 0 Materials for Selected Task:
05-00-00-BMA1 05-00-00-BMA1 12B CARRY OUT AN ARRIVAL AND PRE-DEPARTURE CH 06-100-02 06-100-02 2M1 BODY SECTION - ACCESS PANELS AND DOORS - ( 06-101-01 06-101-01 2A2 FORWARD CARGO COMPARTMENT - ACCESS PAN 4	No Any Materials was Found for Selected Task I
Tools and Equipment Editor: OEM Part Number:	Material List: PAL, Att. PAL, Noun, Description, MIL, BMS, MFC Specification, Document Reference:
Optional Part Number: Description:	Found 8737 Materials in Database:         Part Number:           Filter:         *           0002A0001-100           0009-001           00097-000           9:9667-001-000
Remarks:	002240011-107         Unit         *           00224001-107



3. After the Work Order selection, all task cards, modifications and additional jobs that constitute it, will be displayed. To switch between them use all these tabs:

4. To register all required materials for a Task Card/ Modification/ Additional Job, highlight it from the list. Then, double click necessary material from the Material list, and in the Material Specification Editor enter a unit and quantity (view 4.1). The list of materials is taken from the Parts Catalog (Store Module, Components sub-module).

If you need to register tools, select a 'Tools' tab, then click on and fill out tool data in the emerged editor. Click on the 'Save' button to save (view 4.2).

5. To delete a wrongly registered material, highlight it and click on.

6. When all materials for the Work Order are registered, click on Print button .